


RINK 1520
Most important
parts:



Part No	Designation	Order No.	Remarks
1	Jockey wheel with fixture	15222	
2	Belt cover right	15411	
3	Belt cover left	15412	
4	Stripper left	15426	
5	Stripper right	15009	
6	Clamp rail	15319	
7	Clamping device	15704	
8	Transport roller front	16049	
9	Pedestal	15703	
10	Intermediate roller	16045	
11	Transport roller rear	16072	
12	Shaft for brush roller	16018	
13	Torque support for conveyor belt drive	16039	
14	Torque support for brush roller drive	16055	
15	Connecting sleeve	15128	
16	Complete lock-in lever brake	11007	Special equipment
17	Lighting unit	11009	Special equipment
18	Wheel chock	11016	
19	Holder for wheel chock	10123	
20	Rubber stripper front	11037	
21	Rubber tyre for jockey wheel	10303	
22	Conveyor belt	10385	
23	Spreading roller section	10130	
24	Round reflector	11013	
25	Star handle	11041	
26	Flange bearing dia. 35 mm	11035	Lubrication instructions !
27	Pedestal bearing dia. 25 mm	10133	Lubrication instructions !
28	Pedestal bearing dia. 40 mm	10165	Lubrication instructions !
29	Regulator 25 l	10336	
30	Regulator 12 l	10335	
31	Brush roller shift lever	10668	
32	Conveyor belt shift lever	10669	
33	Conveyor belt gear	10344	Oil change instructions !
34	Hydraulic motor for transport roller	10367	
35	Hydraulic motor for brush roller	10140	
36	Hydraulic hose NW 10x400	10659	
37	Hydraulic hose NW 10x1200	10666	
38	Hydraulic hose NW 10x1400	10657	
39	Feather key A 8x7x30	11000	
40	Feather key A 10x8x30	11040	